

MIROIR AUXILIAIRE

AUXILIARY MIRROR



Installation Instructions

1 Using Phillips screwdriver, release screw in back of mirror casing, while bearing down on screw. (Keep hand under mirror to prevent it from falling out.)

2 Remove mirror from casing and attach casing to top, outer rim of car door mirror, placing it as far as metal clip will allow.

3 Screw both inner screws, by hand, and tighten with enclosed key until secure.

4 Replace mirror, holding it straight so that pin fits squarely into the hole.

5 Insert rear screw and tighten.

Adjust mirror to desired angle by pressing with thumb.

Instructions d'installation

1 Avec un tournevis (ETOILE) Phillips, retirer la vis au dos du receptacle du miroir en appuyant sur la vis (garder la main sous le miroir pour l'empêcher de tomber)

2 Retirer le miroir du receptacle et attacher le receptacle au dessus de la partie extérieure du rétroviseur de l'automobile en le plaçant aussi loin que la planche métallique le permet.

3 Viser les deux vis intérieures à la main et serrer les avec la clef ci-incluse jusqu'à ce qu'elles soient sécurées.

4 Remplacer le miroir, en le tenant droit pour que l'épingle soit bien en place dans le trou.

5 Insérer la vis arrière et serrer.

Ajuster le miroir en poussant avec le pouce.